

MERISH 3 UPDATES

Download all files from: <http://www.hittraxmidi.com/downloads-and-tutorials/>

IMPORTANT - Print instructions and read carefully before commencing updates. Keep instructions by your side and check off each point as you go.

MERISH-PC PROGRAM

Download PC and MAC versions of Merish-PC. Use Merish-PC to add song title, artist, genre, key and other information into your MIDI Files and MP3 backing tracks

UPDATE FIRMWARE

Firmware updates keep your Merish 3 up to date with bug fixes and new features. Updating Merish 3 firmware is easy.

- Download Firmware file **merishupdate.zip** and save to a blank USB
- Insert USB with saved file **merishupdate.mhx** into PEN-HD slot in Merish 3
- Power on Merish 3
- **DO NOT DISTURB OR POWER OFF MERISH DURING UPDATE**
- Wait until update is complete (2 to 3 minutes) then power off
- Remove USB, wait 20 seconds then power on Merish 3

Regards, Hit Trax Support Team
email@HitTraxMIDI.com
SKYPE: HitTrax